

Clarke[®]

American Sanders

Division of
ALTO[®]

**Operator's
Manual**



**FloorCrafter
Belt Sander**

U.S. Patent No. 5,575,710 and No. 6,578,858

READ THIS BOOK

This book has important information for the use and safe operation of this machine. Failure to read this book prior to operating or attempting any service or maintenance procedure to your Clarke American Sanders machine could result in injury to you or to other personnel; damage to the machine or to other property could occur as well. You must have training in the operation of this machine before using it. If your operator cannot read English, have this manual explained fully before attempting to operate this machine.

Si Ud. o sus operadores no pueden leer el Inglés, se hagan explicar este manual completamente antes de tratar el manejo o servicio de esta máquina.

All directions given in this book are as seen from the operator's position at the rear of the machine.

For new books write to: Clarke[®], 2100 Highway 265, Springdale, Arkansas 72764

Table of Contents

| | |
|--|----|
| Operator Safety Instructions | 3 |
| Introduction and Machine Specifications | 5 |
| 230V Electrical Connection Instructions | 6 |
| How to Transport the Machine | 7 |
| One Person | 8 |
| Two People | 9 |
| Machine Set-Up | 9 |
| How to Operate the Machine | 11 |
| Sanding Cuts and Sandpaper | 13 |
| Chatter Wave Prevention | 14 |
| Sander Adjustment Procedures | 15 |
| Dust Shoe | 15 |
| Sanding Pressure | 15 |
| Leveling the Drum | 15 |
| Belt Tracking | 16 |
| Operating Control | 16 |
| Routine Maintenance | 17 |
| Sanding Chamber | 17 |
| Wheels | 17 |
| Dust Bag | 17 |
| Drive Belt | 17 |
| Bearings..... | 18 |
| Rollers | 18 |
| Troubleshooting | 19 |
| Main Assembly Drawing #1 | 22 |
| Main Assembly Parts List #1 | 23 |
| Handle Control Assembly Drawing #2 | 24 |
| Handle Control Assembly Parts #2 | 25 |
| Contact Wheel & Truck Assembly Drawing #3..... | 26 |
| Contact Wheel & Truck Assembly Parts List #3 | 27 |
| Belt Tensioner Assembly Drawing #4 | 28 |
| Belt Tensioner Assembly Parts List #4..... | 29 |
| Dolly Assembly Drawing & Parts List #5..... | 30 |
| Motor Assembly & Parts List #6 | 31 |
| Wiring Diagram..... | 32 |

OPERATOR SAFETY INSTRUCTIONS



WARNING



AVERTISSEMENT



ADVERTENCIA

| | |
|-----------------------|--|
| DANGER means: | Severe bodily injury or death can occur to you or other personnel if the DANGER statements found on this machine or in this Operator's Manual are ignored or are not adhered to. Read and observe all DANGER statements found in this Operator's Manual and on your machine. |
| WARNING means: | Injury can occur to you or to other personnel if the WARNING statements found on your machine or in this Operator's Manual are ignored or are not adhered to. Read and observe all WARNING statements found in this Operator's Manual and on your machine. |
| CAUTION means: | Damage can occur to the machine or to other property if the CAUTION statements found on your machine or in this Operator's Manual are ignored or are not adhered to. Read and observe all CAUTION statements found in this Operator's Manual and on your machine. |



DANGER:



Failure to read the Operator's Manual before operating or servicing this sanding equipment could result in injury to the operator or to bystanders and could cause damage to the equipment. Read and observe all safety statements found in this manual and on the sanding equipment. Make sure all labels, decals, warnings, cautions and instructions are fastened to the equipment. Replace any that are damaged or missing. You must have training in the operation of this equipment before using it. **If the operator is unable to read this manual, have it explained fully before they attempt to use this equipment.**



DANGER:



Sanding/finishing wood floors can create an environment that can be explosive. The following safety procedures must be adhered to:

- Cigarette lighters, pilot lights and any other source of ignition can create an explosion when active during a sanding session. All sources of ignition should be extinguished or removed entirely if possible from the work area.
- Work areas that are poorly ventilated can create an explosive environment when certain combustible materials are in the atmosphere, i.e., solvents, thinners, alcohol, fuels, certain finishes, wood dust and other combustible materials. Floor sanding equipment can cause flammable material and vapors to burn. Read the manufacturer's label on all chemicals used to determine combustibility. Keep the work area well ventilated.
- Spontaneous combustion or an explosion can occur when working with sanding dust. The sanding dust can self-ignite and cause injury or damage. Sanding dust should be disposed of properly. Always empty the sanding dust into a metal container that is located outside of any building(s).
- Remove the contents of the dust bag when the bag is 1/3 full. Remove the contents of the dust bag each time you finish using the equipment. Never leave a dust bag unattended with sanding dust in it.
- Do not empty the contents of the dust bag into a fire.
- Hitting a nail while sanding can cause sparks and create an explosion or fire. Always use a hammer and punch to countersink all nails before sanding floors.



DANGER:

Operating partially assembled sanding equipment could result in injury to the operator or bystander and could cause damage to the equipment or to other property.

- Do not operate this equipment unless it is fully assembled and all guards, doors and covers are secured.
- Keep all fasteners tight.
- Keep all adjustments within manufacturers specifications.



DANGER:



Moving parts on this sanding equipment can cause injury to the operator or bystanders.

- Keep hands, feet and loose clothing away from all moving parts.
- Do not change or adjust the abrasive while the sanding equipment is running.
- Do not service the sanding equipment while it is running.



DANGER:



This sanding equipment requires a supply of electricity. Improper use could result in electrical shock or fire.

- Connect only to an electrical source matching what is shown on the equipment name-plate.
- Do not use this sanding equipment on an ungrounded electrical circuit. Consult an electrician if you suspect the circuit is not properly grounded.
- Do not use this sanding equipment with a damaged electrical cord. Inspect before each use.
- Avoid striking the electrical cord with the abrasive. Always lift the electrical cord over the sanding equipment.
- Do not use the electrical cord to move the sanding equipment.
- Disconnect the electrical source before servicing this equipment.



WARNING:



In the event of a bag fire, injury can occur to the operator if the operator is tied or strapped to equipment. Use operating belt properly (follow procedure on page 8).



WARNING:



Injury to the operator or bystander can occur if protective gear is not worn while sanding. Always use eye, ear, and respiratory protection while performing any sanding operation.



WARNING:

Bodily injury could occur if power is applied to the equipment with the power switch already in the "ON" position. Always check to assure that the power switch is in the "OFF" position before connecting power supply.



CAUTION:

Maintenance and repairs performed by unauthorized personnel could result in damage or injury. Maintenance and repairs performed by unauthorized personnel will void your warranty. Servicing of this unit must always be referred to an authorized Clarke American Sanders distributor.



CAUTION:

Use of this equipment to move other objects or to climb on could result in injury or damage. Do not use this equipment as a step or furniture. Do not ride on this equipment.



CAUTION:

Damage could occur to the equipment if not properly kept in a dry building for storage. Store the equipment in a dry building.



CAUTION:


The equipment is heavy. When transporting the equipment, remove the motor. Get help to lift the equipment and motor.



CAUTION:

Serious damage to the floor can occur if the sanding equipment is left running in one spot while the sanding drum is in contact with the floor. To avoid damage to the floor, feather cut in at a normal sanding rate. Do not dwell while lowering or raising the contact wheel. Always sand at a constant rate.

Introduction and Machine Specifications



| MODEL | 07104A | 07111A | 07117A |
|--------------------------|-------------------------------|---------------------------------|--------------------------------------|
| Electrical Requirements | ~208-240V 60Hz | ~220-240V 50Hz | ~220-240V 50Hz |
| Amperage | 15.7 | 11.8 | 11.8 |
| Sound Level (Lpm) | 93.0 dB(A) | 96.2 dB(A) | 96.2 dB(A) |
| Vibration | < .15 inches/s | 2.88 m/s ² rms | 2.88 m/s ² rms |
| Contact Wheel Rate (rpm) | 2450 | 2042 | 2042 |
| Abrasive Rate | 4500 ft./min. | 3750 ft./min. | 1143 meter/min |
| Fan Flow Rate | 234 cfm | 195 cfm | 92 liters/s |
| Drum Pressure Settings | 80 lbs., 70 lbs., 60 lbs. | 80 lbs., 70 lbs., 60 lbs. | 36 kg, 32 kg, 27 kg |
| Abrasive Size | 29½" x 7 7/8" | 29½" x 7 7/8" | 750 mm x 200 mm |
| Motor | 4 Hp Continuous | 2.2 kW Continuous | 2.2 kW Continuous |
| Overload Protection | Magnetic Circuit Breaker | Magnetic Circuit Breaker | 13A Fuse |
| Operating Controls | Adjustable Lever/Grip | Adjustable Lever/Grip | Adjustable Lever/Grip |
| Leveling Controls | Externally Adjustable | Externally Adjustable | Externally Adjustable |
| Electrical Cable | 50' 10-3 SJO with L6-20P Plug | 100' 12-3 SJO with AU2-15P Plug | 15 m HO7RN-F3GI .5 with UK1-13P Plug |
| Operating Wheels | 80 Durometer Clear Urethane | 80 Durometer Clear Urethane | 80 Durometer Clear Urethane |
| Weight | 204 lbs. | 204 lbs. | 92.7 kg |
| Dimensions | 35" x 13 3/4" x 38 3/4" | 35" x 13 3/4" x 38 3/4" | 890mm X 350mm x 984mm |
| Shipping Values | | | |

NOTE: *rpm (Revolutions per minute)
 *sfm (Surface feet per minute)
 *cfm (cubic feet per minute)

CAUTION: Your equipment may be inappropriate on some installations. Some softer woods used in flooring cannot support the pressure created by hard wheels.

Always consult with the flooring manufacturer on the proper installation, preparation, and finishing of their product. Determine suitability of your equipment in preparing the product.

230V Electrical Connection Instructions

CAUTION: This machine will operate only on AC frequency and on electrical voltage shown on the motor nameplate. Make sure you have the correct frequency and voltage before connecting the power cord to an outlet. See example in figure 1.

This machine must be connected to an electrically ground circuit in order to protect the operator from electric shock. This machine has an approved power cord with three conductors as well as a plug with three terminals. Connect the plug into a three holed receptacle. For maximum protection against electric shock, use a circuit that is protected by a ground fault circuit interrupter.

DANGER: Electrocutation could occur if the machine is exposed to water or rain. Keep the machine in a dry building.

DANGER: Electrocutation could occur if machine is improperly connected to the electrical system. To prevent possible electric shock, always use a 3-wire electrical system connected to an electrical ground. For maximum protection against electrical shock, use a circuit that is protected by a ground fault circuit interrupter. Consult your electrical contractor.

DANGER: Electrocutation could occur if the ground pin is tampered with in any way. Do not cut, remove, or break the ground pin. Do not try to fit a three-terminal plug into a receptacle or connector body other than a three plug receptacle or connector body. If the outlet does not fit the plug, consult your electrical contractor.

DANGER: Electrocutation could occur if the machine is used with a damaged plug or power cord. If the cords or plugs are worn or damaged in any way, have them replaced by an authorized service person or electrician.




Figure 1

Extension Cords

Use only an approved three-pronged extension cord with two main conductors and one earthing conductor. This machine is equipped with a power cord. When greater range is needed follow the table below to determine cable gauge of additional footage. Refer to the following chart for extension cord information.

| Feet/Wire Gauge (Stranded Copper) | | |
|-----------------------------------|----------|---------------------|
| Source Voltage | 0 - 100' | 100 - 250' |
| 208 | 6 | Use Voltage Booster |
| 230 | 10 | 8 |

If motor appears to labor or takes a considerable longer time to come up to speed reduce sanding pressure.

How to Transport the Machine

WARNING: The machine is heavy. Remove the motor from the machine before transporting. Get help loading the machine and motor. Use proper lifting techniques.

Transporting the Machine - Using the Dolly Cart

CAUTION: When deploying the dolly, the drum will contact the floor or ground over which the machine is resting. Care should be taken to avoid surfaces which might damage or contaminate the drum.

CAUTION: While transporting using the dolly, abrupt changes in the direction of travel or the surface over which the machine is being transported could cause the machine to tip over. Also, the machine is more likely to tip over when transporting across inclined surfaces.

Attach the dolly to the rear of the machine as follows:

1. Open the quick release levers (2A) and unscrew the adjustment nuts (2B) to allow installation of the dolly. (See figure 2)
2. Insert the quick release skewers into the dolly brackets and immediately tighten the adjustment nuts until the dolly mechanism will just swing free.

Deploy the dolly under the machine as follows:

1. With the dolly mechanism in place as described above, tip the machine by lifting up on the operators handle to raise the rear of the machine off the floor/ground until the dolly swings under the machine. (See figure 3)
2. Hold the dolly in position using your foot and allow the machine to tip back and rest on the dolly wheels. (See figure 4)
3. Tip the machine back on all four wheels and close the quick release levers for transport. Some adjustment of the quick release skewers may be necessary to allow the levers to be tightened securely.

Removing/Storing the dolly:

The dolly can be stored on the machine in the "UP" position or it can be removed and stored separately.

1. Open the quick release levers to loosen the dolly.
2. Lift up on the operators handle to tip the machine forward.
3. Swing the dolly out from under the machine and lower the machine until it rests on its own wheels.

CAUTION: Be careful when lowering the machine. The dolly will swing back toward the operator as the machine is lowered.




Figure 2




Figure 3




Figure 4

How to Transport the Machine (cont.)

4. To store the dolly in the "UP" position, swing the dolly up against the top of the mainframe as far as it will travel and close the quick release levers to secure it in place. (See Figure 5)
5. To remove the dolly, loosen the quick release adjustment nuts until the levers and nuts clear the counter-bore on the dolly brackets, and remove the dolly.
6. Tighten the adjustment nuts until the quick release levers can be closed to secure the dolly in place.




Figure 5

Transporting the Machine - One Person

NOTE: This is accomplished by removing the motor from the chassis and transporting the motor and chassis separately.

To transport the machine, follow this procedure:

1. Make sure the power cable is disconnected from the electrical outlet.
2. Release the tension on the drive belts using the quick release lever. (See Figure 6A)
3. Open the belt guard by pulling on the handle immediately above the left truck wheel. (See Figure 6B)
4. Remove the drive belts from the machine
5. Disconnect the motor pigtail from the handle pigtail. (See Figure 7)
6. Unscrew the motor mounting knobs to loosen the motor. (See Figure 8)
7. Straddle the motor and grasp the motor lift handle. Using your legs, lift the motor off the chassis and take it to the work site.
8. Lift the chassis by grasping the front and rear handles. Lift the frame and bring the belt guard against your chest. Take the chassis to the work site.




Figure 6




Figure 7

To assemble the machine after transporting, follow this procedure:

1. Open the belt guard door. Place the motor assembly on the chassis and screw the motor mounting knobs sufficiently to engage and secure the motor.
2. Install the drive belts. Tighten the belts using the belt tension quick release lever.
3. Check the tension on the belts and close the belt guard door.




Figure 8

CAUTION: Premature bearing failure can occur if the fan belt is set too tight. The fan belt should deflect $\frac{1}{2}$ " at the center of the span with 5 lbs. of pressure.

NOTE: It is necessary to adjust the fan belt independently during this procedure or during replacement. The idler pulley is factory adjusted.

Transporting the Machine by Carrying - Two People

1. Person #1 places his hands under the front of the machine's main casting.
2. Person #2 lifts the machine by the operating handle.

Machine Set-Up

To set-up your machine follow this procedure:

1. Familiarize yourself with the machine and read all danger, warning and caution statements. Make sure all operators of this machine have read this Owner's Manual. If they cannot read English, have the manual explained fully before allowing anyone to operate the sander.
2. Locate the power supply. The receptacle should be compatible with the plug. The receptacle must be grounded and must be fused (30 amp) to avoid an electrical hazard.
3. Clip the dust bag to the elbow. (See figure 9) Cross the strings on the dust bag and draw tight over the flare on the elbow. Wrap the string around the elbow and secure.
4. Wind the power cord through the cable arm. (See figure 10) Keep the power cord out of path of equipment.
5. Pull the draw latch forward to release the access door to gain entry to the sanding chamber.
6. Rotate the release lever forward. (See Figure 11)




Figure 9




Figure 10




Figure 11

Machine Set-Up (Cont)

7. Install a new abrasive belt by sliding the abrasive over the tension roller and contact wheel.
(See figure 12)
8. Rotate the release lever backward to tighten the abrasive belt.

CAUTION: Do not force the release lever. Doing so can damage the tracking mechanism and cause the abrasive belt to mis-track.







Figure 12


9. Make sure the motor circuit breaker is in the "Off" position. Plug the pigtailed power cord into the handle. Twist the cord connection clockwise to lock.
10. Jog (turn on momentarily) the motor circuit breaker while observing the belt tracking. Follow the procedures outlined in the "Sander Adjustment Procedures" on page 16 to correct the belt tracking. There is also a label on the inside of the access door that outlines the belt adjustment.
11. Close the access door. Place the end of the draw latch over the keeper on the access door and push the draw latch flat against the main-frame to secure.


How to Operate the Machine

 **DANGER:** Sanding/finishing wood floors can create an environment that can be explosive. Cigarette lighters, pilot lights and any other source of ignition can create an explosion when active during a sanding session. All sources of ignition should be extinguished or removed entirely if possible from the work area.

 **DANGER:** Work areas that are poorly ventilated can create an explosive environment when certain combustible materials are in the atmosphere, i.e., solvents, thinners, alcohol, fuels, certain finishes, wood dust and other combustible materials. Floor sanding machines can cause flammable material and vapors to ignite. Read the manufacturer's label on all chemicals used to determine combustibility. Keep the work area well ventilated.

 **DANGER:** Sanding dust can spontaneously ignite and cause an injury or damage. Sanding dust should be disposed of properly. Always empty the sanding dust into a metal container. Remove the contents of the dust bag when the bag is 1/3 full.

 **DANGER:** Sanding dust can spontaneously ignite and cause an injury or damage. Remove the contents of the dust bag each time you finish using the machine. Always dispose of the dust in a metal container located outside of the building. Never leave a dust bag unattended with sanding dust in it. Do not empty the contents of the dust bag into a fire.

 **DANGER:** Hitting a nail while sanding can cause sparks and create an explosion or fire. Always use a hammer and punch to countersink all nails before sanding floors.


To operate the machine follow this procedure:

1. Before sanding, decide on best approach for sanding desired area. If the floor is uneven, it may be necessary to sand diagonally to the direction that the floor is laid. This will help "pull" or stretch low and high spots in the floor over a greater area, producing a flatter surface. Preliminary cuts should be performed at angles approximately 15° to the direction of the wood grain. Cut direction should change on successive cuts with the final cut performed in the direction of the wood grain. This will minimize the tendency of waves to form and provide the most even floor surface.


When sanding the area, work in a way so that you are moving away from where the cord set enters the room. This will help to avoid entanglement with the cord set and eliminate the need to move the cord set out of the way so frequently.

Work the area in a way that avoids interruption or termination points (an end of pass.) Make long continuous passes.

2. Swing cable arm to side of machine opposite the direction you intend to work. Rotate elbow on dust pipe until dust bag rest on motor. This will maintain balance and sanding pressure as the dust bag fills. The machine should be operated with the dust bag in this position whenever possible.
3. If the operating belt (Clarke American Sanders PN 60724A) is used proceed as follows:
 - a. Position the operating belt around waist.
 - b. Cross the straps at the waist. See figure #13.
 - c. Slide the belt loop end over the handle on the control lever side. Adjust the length as needed.
 - d. Wrap the remaining strap around the opposite side of the handle, and hold it in place with your hand.

 **WARNING:** Serious operator injury could occur if the operator has tied or strapped the loose end of the operator's belt strap to the machine. Always wrap the strap so that you can let go and get away quickly in case of bag fire or explosion.

4. Turn the control switch to the "On" position.

 **CAUTION:** To prevent damage to the floor, make sure the machine is in motion when the contact wheel is engaged with the floor.

5. Feather-cut in by easing the contact wheel down onto the surface with the control lever while the sander is in motion.

6. When contact wheel is fully engaged with the surface, gradually adjust your pace for adequate finish removal. Keep sander in motion while the contact wheel is engaged with the surface or dwell marks will occur.
7. Move the machine in the direction of the grain in the wood whenever it is possible. Sand the surface at a constant pace.
8. Gradually feather-cut out at the termination point by easing the contact wheel up with the control lever. (See Figure 13)
9. Repeat technique described in steps 5, 6, 7, and 8 and sand back down pass just made. When completed, begin a new pass by overlapping previous pass half the width of the abrasive. Stagger termination points to prevent a distinct ridge and a better blend when edging.
10. Empty contents of the dust bag into a metal container located outside the building. Dust bag should be emptied whenever full, as indicated on bag.




Figure 13

⚠ WARNING: Do not overfill dust bag or serious fire may result. Never leave a dust bag containing dust unattended. Sanding dust can spontaneously ignite and cause a fire or explosion. Use only genuine Clarke American Sanders replacement bags.

⚠ CAUTION: An overfilled dust bag may affect machine balance and performance. Do not handle or disturb dust bag and elbow while sanding or damage to the floor may occur.

Sanding Cuts and Sandpaper

Initial Cut

The purpose of the initial cut is to remove old finish and gross imperfections on the floor surface. The sanding equipment should be adjusted to heavy sanding pressure setting and a coarse abrasive belt should be used. If the surface is severely damaged by deep scratches, preexisting dwell marks, uneven planks, etc., it may be necessary to sand across or diagonally to the grain to restore evenness to the surface. If these conditions are not present, the initial cut should be done in the direction of the grain.

If glazing, loading, or burning takes place immediately into an initial cut, select a coarser abrasive. If this should occur during an initial cut, the abrasive has dulled and must be replaced.

Final Cuts

The purpose of a finishing cut is to remove the scratches produced during the initial cut. Use a fine (60 - 80 grit) grain abrasive and a reduced sanding pressure setting.

If the surface remains rough after a finishing cut, it may be necessary to use an even finer grain of abrasive (80 - 100 grit). Care should be taken in selecting the grit size of the abrasive. A very fine grain will close the pores on a wood floor making admission of a stain difficult.

If glazing or burning should occur immediately into a finishing cut, reduce the sanding pressure. If it should occur during a finishing cut, the abrasive has dulled and must be replaced.

Abrasive Belts

Note: All part numbers listed are for a carton of 10 belts

| Grain | Use | Aluminum Oxide | Silicon Carbide | Ceramic Alum.Oxide |
|----------|--|----------------|-----------------|--------------------|
| 16 grit | For removing gross imperfections and restore evenness to old flooring. To remove build-up of paints and varnishes. | - | 945844 | - |
| 36 grit | For first sanding of new flooring (maple, oak). For removing minor imperfections and finishes from old flooring. | - | 945842 | 945901 |
| 40 grit | For first sanding of new flooring (oak, walnut). For removing minor imperfections and finishes from old flooring. | - | 945841 | 945902 |
| 50 grit | For first sanding of new flooring (cedar, pine, fir) For cleanup of 16 grit. | - | 945840 | 945903 |
| 60 grit | For cleanup from initial cut 36 - 40 grit. | 945839 | - | 945904 |
| 80 grit | For final sanding of certain hardwoods. For cleanup of initial cuts (50 grit). | 945838 | - | 945905 |
| 100 grit | For final sanding of certain hardwoods where a smooth surface is desired. | 945837 | - | 945909 |
| 120 grit | For final sanding of certain conifers. | 945836 | - | 945910 |
| 150 grit | For final sanding of certain conifers where a smooth surface is desired. | 945835 | - | 945911 |
| 180 grit | For surface roughing between coats of finish. | 945834 | - | - |

Chatter Wave Prevention

Clarke Sanders are designed and manufactured to the most rigid tolerances. However, after a finishing cut it is possible to see “chatter” or “waves”.

The best guarantee to remove the chatter is to finish the floor with a rotating horizontal sander, such as Clarke’s Sander 16.

To minimize chatter when using a belt or drum sander the following steps should be taken:

1. DRUM MARKS...are caused by the operator lowering the drum to the floor without forward traverse. These marks should be removed by cutting at a 45 degree angle to the mark. Cutting at the mark while maintaining the same path will only increase the mark depth and width. (See figure 14)
2. UNEVEN WALKING SPACE...can leave lengthy “waves”. The machine cuts more material during the slower pace. Pay particular attention to a steady, even pace.
3. EXCESSIVE LIGHT CUTS...may reveal high spots on the paper/contact wheel and cause chatter. Take a heavier cut and increase the pace.
4. DEBRIS...lodged between the paper and the drum will leave chatter. On a belt sander, debris may be adhered to the drum. Insure the drum is clean and free of debris before placing the paper on.
5. ABRASIVE QUALITY...may vary. Belt seams can be thicker on low quality paper and cause chatter. Use only Clarke specified sandpaper. Store abrasive according to manufacturers recommendation.




Figure 14

PROPER CARE OF YOUR MACHINE CAN MINIMIZE CHATTER AND WAVES.

1. V-BELTS...can cause vibration and chatter if they are of low quality. Use only belts specified by Clarke.
2. TRUCK AND CASTER WHEELS...with flat spots, out-of-roundness, or debris adhered to their surface can cause “waves” or a “chatter effect”. Always clean and inspect all wheels before starting to sand, and before the finish cut. Replace or true the wheels if found to be out-of-round. Never allow the sander to stand on hard surfaces for lengthy periods of time.
3. DUST PICK-UP SHOES...may need adjusted differently for different materials that are to be sanded. An improperly adjusted shoe will leave trailing debris that will be run over by the wheels and cause “random waves”.
4. CONTACT WHEELS (DRUMS)...may be out-of-round and cause “chatter”. Contact your Clarke dealer for assistance to true or replace the drum.
5. BEARINGS...in the motor, drum, or fan system may become worn and induce vibration which could cause “chatter”.
6. PULLEYS...that are damaged or severely worn can induce vibration and cause “chatter”. Contact your Clarke dealer for assistance.
7. SANDPAPER TENSION...should always be released when the machine is shut off for 10 minutes or longer to avoid compression of the drum.

NOTE: Clarke is not responsible for rework of floors that are unacceptable to the customer. It is your responsibility to insure your equipment is in proper operating order, and that you use the right machine for the job.

Sander Adjustment Procedures

⚠ DANGER: Electrocutation could occur if maintenance and repairs are performed on a unit that is not properly disconnected from the power source. Disconnect the power supply before attempting any maintenance or service.

⚠ DANGER: Moving parts of this machine can cause serious injury and/or damage. Keep hands, feet and loose clothing away from all moving parts of the sander.

The following information provides details on how to adjust different features/controls of the sander.

Dust Shoe

To adjust the dust shoe follow this procedure:

1. Disconnect machine from power supply.
2. Loosen the three screws fastening the dust shoe to the chassis.
3. Adjust the dust shoe down to reduce clearance.
4. Adjust the dust shoe up to increase clearance.
5. Align the dust shoe to the chassis and tighten screws. (See figure 15)

Sanding Pressure

There are three pressure settings to select from: heavy, medium and light. The lower the position the heavier the setting. To change settings, raise the lever and place in desired position. (See figure 16)

Leveling the Drum

⚠ CAUTION: The belt tracking maybe adversely effected if machine is operated unlevelled.

The machine is leveled at the factory set and no adjustments should be necessary. After any maintenance is performed to the carriage system, the pointer on the leveling bracket must be returned to original mark (See figure 17).

If it is necessary to reset level after replacing wheels follow this procedure:

1. Lower the contact wheel to the floor.




Figure 15




Figure 16




Figure 17

Sander Adjustment Procedures (cont)

2. Drive the adjusting screw **in**, to sand heavier on the left (the drive belt side). Back the adjusting screw **out**, to sand heavier on the right (the side opposite the drive belts). Test the setting on an even surface. Make further adjustments if necessary.
3. Mark new pointer location on main frame

Belt Tracking

⚠ WARNING: Injury to the operator could occur if any machine adjustments are made while the motor is running. Do not attempt to make any adjustments while the machine is plugged in or running.

To adjust the belt tracking follow this procedure:

1. Locate the belt tracking adjuster screw. (See figure 18A)
2. Hold the belt tracking adjuster screw and loosen the locknut. (See figure 18B).
3. Rotate the tracking adjuster screw counterclockwise to move the belt in.
4. Rotate the tracking adjuster screw clockwise to move the belt out.
5. Test adjustment and tighten the locknut.




Figure 18

Operating Control

To **increase** the travel or extend the reach on the grip control follow this procedure:

1. Loosen the locknut on the control rod. (See figure 19A)
2. Screw the control rod adjuster (See figure 19B) **"In"** until the desired reach is found.
3. Tighten the locknut.




Figure 19

Sanding Adjustment Procedures (Cont)

To **decrease** the travel or reduce the reach on the grip control follow this procedure:

1. Loosen the locknut on the control rod.
(See figure 20A)
2. Screw the control rod adjuster "**out**" until desired reach is found.
3. Tighten the locknut.

Routine Maintenance

The following items need to be periodically inspected and maintained to keep your sander in good working condition.

Sanding Chamber

Periodically blow out the sanding chamber to prevent large accumulations of debris which could interfere with the performance of the tension roller.

Wheels

Periodically remove the debris from the truck and caster wheels. Debris can cause waves on a sanded surface.

Dust Bag

Remove the dust bag from the machine and shake it thoroughly to remove the sanding dust from the dust bag. Turn the dust bag inside out and machine wash in cold water to prevent pore blockage and loss of dust recovery.

Drive Belt

Drive belt tension is factory set and should not require adjustment. Periodically check the drive belt tension. Proper belt tension is achieved when 10 lbs. of force at the mid-span of the belt produces $\frac{1}{2}$ inch of deflection.

To increase belt tension, release tension using quick release lever (See Figure 6).

Turn the adjustment screw "OUT" (See Figure 21) one quarter turn. Restore tension using quick release lever and check adjustment. Repeat this process if necessary. To lower tension, the adjustment screw is turned "IN".




Figure 20




Figure 21

Bearings

Periodically check the bearings for wear or damage according to the following schedule:

| | |
|-----------------------|---------------------------------|
| <i>Guide rollers</i> | after 1 st 650 hrs. |
| <i>Idler pulley</i> | after 1 st 1500 hrs. |
| <i>Fan shaft</i> | after 1 st 2500 hrs. |
| <i>Tension roller</i> | after 1 st 2500 hrs. |
| <i>Arbor shaft</i> | after 1 st 5000 hrs. |
| <i>Motor shaft</i> | after 1 st 5000 hrs. |

Rollers

Periodically check the guide rollers and the tension roller for wear.

Troubleshooting

| Problem | Cause | Action |
|--|--|---|
| Drive belts slip. (Squeaking or squealing sound) | Insufficient tension. | Tension drive belt as described in adjustment procedures. (See pg. 7) |
| | Worn belts. | Replace belts. |
| Squealing, growling or grinding noise coming from machine. | Damaged and/or worn bearing. | Remove drive belts, rotate arbor motor, fan, shafts and idler pulley to locate dragging or rough bearing. Contact an authorized dealer. |
| Dust pickup is poor. | Dust bag is over 1/3 full. | Empty contents of bag. |
| | Dust bag is dirty. | Shake debris from bag and wash. |
| | Dust shoe is improperly adjusted. | Readjust dust shoe. |
| | Dust chute is obstructed. | Remove fan cover and clear throat. |
| Motor will not start. | Defective motor starter. | Contact an authorized dealer. |
| | Defective start capacitor. | Contact an authorized dealer. |
| | Defective electronic start switch. | Contact an authorized dealer. |
| | Low voltage from poor connection. | Contact an authorized dealer. |
| | Defective motor. | Contact an authorized dealer. |
| | No power. | Check power supply and connections. |
| Motor runs sluggishly. | Low voltage from excessive footage, undersized extension cord, or poor connection. | Locate power source nearer to work site. Decrease sanding pressure. |
| | Defective run capacitor. | Contact an authorized dealer. |
| | Defective motor. | Contact an authorized dealer. |
| Motor circuit breaker trips/ repeatedly trips. | Excessive load. | Contact an authorized dealer. |
| | Defective electronic start switch. | Contact an authorized dealer. |
| | Defective motor starter. | Contact an authorized dealer. |
| | Low voltage from poor connection. | Contact an authorized dealer. |
| | Defective motor. | Contact an authorized dealer. |
| | Defective capacitor. | Contact an authorized dealer. |
| Uneven cuts. | Leveling out of adjustment. | Readjust leveling. Fig. 13 page 15. |
| | Abrasive belt tracking. | Adjust belt to track towards the edge of drum with deepest cut. |

Troubleshooting

| Problem | Cause | Action |
|---|--|---|
| Burning or glazing. | Dull abrasive. Excessive sanding pressure. Too fine of an abrasive belt. | Replace abrasive. Decrease sanding pressure setting. (Fig. #12, page 14). Use coarser abrasive. |
| Slow cutting. | Dull abrasive. Too fine of an abrasive belt. Insufficient sanding pressure. | Replace abrasive. Use a coarser abrasive belt. Increase sanding pressure setting. (Fig. #12, page 14). |
| Waves on sanded surface. | Debris on wheels. Flat spot on tire(s). | Remove and clean wheels. Replace tires. |
| Chatter marks on sanded surface. (Close evenly spaced ripples) | See Chatter Wave Prevention, page 13. | See Chatter Wave Prevention, page 13. |
| Difficult to actuate tension release lever. | Debris interferes with mechanism Worn sleeve bearing. Galled linkages. | Blow out sanding chamber. Remove and disassemble mechanism. Clean out. Replace. Lubricate with WD-40. |
| Abrasive belt hunts (seeks). | Worn washers. Worn sleeve bearing. High edges on contact wheel. | Replace (items #84 & 88, pg. 20,21). Check for excessive play, replace. Contact an authorized dealer or replace the contact wheel. |
| Abrasive belt will not track. | Extreme difference in side-to-side length of belt. High edge on contact wheel. | Replace abrasive belt. Check several different abrasive belts. Contact an authorized dealer or replace the contact wheel. |
| Abrasive belt tears along its length. | Debris built-up on (top) tension roller. | Clean tension roller. |

Clarke[®]

American Sanders




**FloorCrafter
Belt Sander
Section II
Parts and Service Manual**

(70255B)

U.S. Patent No. 5,575,710 and No. 6,578,858

Clarke®
American Sanders
FloorCrafter
Main Assembly Drawing #1 6/02




Clarke
American Sanders
FloorCrafter Belt Sander
Main Assembly Parts List #1 1/04

| Ref No. | Part No | Description | Qty |
|---------|---------|--|-----|
| 1 | 60342A | Seal, Felt | 1 |
| 2 | 10142A | Asm., Dust Tube Elbow | 1 |
| 3 | 10144A | Asm., Tube, Dust | 1 |
| 4 | 920342 | Nut, $\frac{3}{8}$ -16 Lock | 1 |
| 5 | 20022A | Mainframe | 1 |
| 6 | 81202A | Nut, $\frac{7}{16}$ -14 L.H. | 1 |
| 7 | 60476A | Pin, Motor Mount | 2 |
| 8 | 68010A | Stud, Idler Arm | 1 |
| 9 | 60414A | Arm, Idler | 1 |
| 10 | 67875A | Spacer | 1 |
| 11 | 57801A | Ring, Retaining | 1 |
| 12 | 902619 | Bearing | 1 |
| 13 | 81108A | Nut, Lock $\frac{3}{8}$ -24 | 1 |
| 14 | 66170A | Pulley, Idler | 1 |
| 15 | 962216 | Screw, $\frac{3}{8}$ -16 x $1\frac{1}{4}$ | 1 |
| 16 | 80017A | Bolt, $\frac{3}{8}$ x $2\frac{3}{4}$ | 1 |
| 17 | 20023A | Guard, Belt | 1 |
| 18 | 80131A | Screw, Carriage, $\frac{1}{4}$ -20 x $\frac{3}{4}$ | 1 |
| 19 | 85702A | Screw, $\frac{1}{4}$ -20 x $\frac{3}{4}$ | 1 |
| 20 | 60384A | Bracket, Latch | 1 |
| 21 | 68393A | Tube, Latch | 1 |
| 22 | 81102A | Nut, $\frac{1}{4}$ -20 ESNA | 2 |
| 23 | 60366A | Pulley, Fan | 1 |
| 24 | 920196 | Nut | 1 |
| 25 | 877304 | Ring, Retaining, Internal | 1 |
| 26 | 51111A | Bearing, Ball | 2 |
| 27 | 915561 | Key | 2 |
| 28 | 85812A | Screw, $\frac{5}{16}$ -18 x $\frac{7}{8}$ | 3 |
| 29 | 171101 | Nut, $\frac{3}{8}$ -16 Flange | 1 |
| 30 | 23301A | Fan | 1 |
| 31 | 61602A | Collar | 1 |
| 32 | 902567 | Beaing, Ball | 1 |
| 33 | 20026A | Cover, Fan | 1 |
| 34 | 920110 | Nut, $\frac{5}{16}$ -18 | 1 |

| Ref No. | Part No | Description | Qty |
|---------|---------|---|-----|
| 35 | 60370A | Shaft, Fan | 1 |
| 36 | 962870 | Screw, $\frac{3}{8}$ -16 x $\frac{7}{8}$ Button | 1 |
| 37 | 87000A | Washer | 1 |
| 38 | 51215A | Bearing, flange | 1 |
| 39 | 87052A | Washer | 2 |
| 40 | 61600A | Clip-dust | 1 |
| 41 | 60368A | Lever, Belt Tensioning | 1 |
| 42 | 86111A | Screw, $\frac{1}{4}$ -20 x $\frac{1}{2}$ | 1 |
| 43 | 980657 | Washer, Lk $\frac{1}{4}$ Std | 1 |
| 44 | 60397A | Cover, Dust Throat | 1 |
| 45 | 85517A | Screw, 10-24 x $\frac{1}{2}$ | 13 |
| 46 | 60392A | Bumper, Front | 1 |
| 47 | 51219A | Rivet, Nylon | 3 |
| 48 | 962727 | Screw, 8-32 x $\frac{1}{2}$ | 2 |
| 49 | 52338A | Latch, Draw | 1 |
| 50 | 87700A | Screw, $\frac{1}{4}$ -20 x $\frac{1}{2}$ | 5 |
| 51 | 60386A | Handle, Mainframe | 1 |
| 52 | 51093A | Cam, Belt Release | 1 |
| 53 | 60482A | Spacer | 1 |
| 54 | 962565 | Screw | 1 |
| 55 | 60475A | Bolt, Adjustment | 2 |
| 56 | 962216 | Screw, $\frac{3}{8}$ -16 x $1\frac{1}{4}$ | 1 |
| 57 | Ref. | Assembly, Motor | 1 |
| 58 | 51039A | Belt, Fan | 1 |
| 59 | 51024A | Belt Drive | 1 |
| 60 | 52420A | Cover, Lever | 1 |
| 61 | 930093 | Rivet, $\frac{1}{8}$ x $\frac{5}{16}$ | 2 |
| 62 | 74045A | Plate, Danger | 1 |
| 63 | 50954A | Bag | 1 |
| *64 | 10332A | Tool Kit (includes * items) | 1 |
| * | 51273A | $\frac{3}{32}$ Hex Key (incl. in #64) | 1 |
| * | 51274A | $\frac{7}{32}$ Hex Key (incl. in #64) | 1 |
| * | 51347A | Pouch (incl. in #64) | 1 |
| * | 59810A | Wrench $\frac{9}{16}$ x $\frac{7}{16}$ (incl. in #64) | 2 |

Clarke®
American Sanders
 FloorCrafter Belt Sander
 Handle Control Assembly Drawing #2 1/04




Clarke
American Sanders
FloorCrafter Belt Sander
Handle Control Assembly Parts List #2 1/04

| Ref No. | Part No | Description | Qty |
|---------|---------|--|-----|
| 1 | 42200A | Cord Set | 1 |
| | 40010A | Cable Asm. AU2-15P | 1 |
| | 40673A* | Cable Asm. UK1-13P | 1 |
| 2 | 53538A | Rod, End $\frac{3}{8}$ -24 L.H. | 1 |
| | 60387A | Rod, Control | 1 |
| 4 | 920204 | Nut, $\frac{3}{8}$ -24 Hex Jam | 1 |
| | 80035B | Bolt, Shoulder $\frac{3}{8}$ x $\frac{1}{4}$ | 1 |
| | 53537A | Rod, End, $\frac{3}{8}$ -24 R.H. | 1 |
| | 898203 | Spacer, Rod End | 1 |
| | 80155A | Bolt, Shoulder $\frac{1}{2}$ x $\frac{5}{8}$ | 1 |
| | 962727 | Screw, 8-32 x $\frac{1}{2}$ | 3 |
| | 962727 | Screw, 8-32 x $\frac{1}{2}$ | 7* |
| | 80132A | Screw, $\frac{1}{4}$ -20 x $\frac{3}{4}$ | 2 |
| 10 | 43501A | Inlet, Flanged | 1 |
| 11 | 43501A | Inlet, Flanged | 1 |
| 12 | 920110 | Nut, Lk $\frac{5}{16}$ -18 | 1 |
| 13 | 85313C | Screw, 6-32 x $\frac{3}{8}$ Pan Hd | 4 |
| 14 | 25601A | Lever, Control | 1 |
| 15 | 980607 | Washer, #6 Tooth Pltd. | 4 |
| 16 | 20016A | Control Housing | 1 |
| 17 | 48900A | Wire Assembly | 1 |
| 18 | 64405A | Handle, Steering | 1 |
| 19 | 41411A | Circuit Breaker, 30 Amp | 1 |
| 20 | 81109A | Nut, Hex, Elastic, Lock, 8-32 | 1 |
| 21 | 21904C | Clamp, Steering Handle | 1 |
| 22 | 85818A | Screw, $\frac{5}{16}$ -18 x $2\frac{1}{2}$ Hx Hd | 1 |
| 23 | 49023A | Wire, Assembly | 1 |
| 24 | 10155A | Assy, Cordholder | 1 |
| 25 | 51220A | Bumper, Plastic | 1 |
| 26 | 85613A | Screw, 8-32 x $\frac{7}{8}$ | 1 |
| 27 | 980982 | Washer, #10 SAE, Flat Hd | 1 |
| 28 | 81112A | Nut, Lk., $\frac{5}{16}$ -18 | 1 |
| 29 | 80026A | Bolt, Shoulder, $\frac{3}{8}$ x $\frac{1}{2}$ | 1 |
| 30 | 87619A | Washer, Flat, .63 x .38 x .03 | 1 |
| 31 | 85517A | Screw, 10-24 x $\frac{1}{2}$ | 10 |
| 32 | 980022 | Washer, Wave | 2 |
| 33 | 87618A | Washer, Flat | 1 |
| 34 | 60372A | Arm, Cord | 1 |
| 35 | 980699 | Washer | 2 |
| 36 | 51074A | Clamp, Cable | 2 |
| 37 | 60374A | Clamp, Retainer | 2 |
| 38 | 41917A | Cord, Interconnecting | 1 |
| 39 | 10145A | Mount, Handle Control | 1 |
| 40 | 962288 | Screw, $\frac{3}{8}$ -16 x 1 | 4 |
| 41 | 45608A | Plug (for 42200A) | 1 |
| | 40024A | Plug (for 40010A) | 1 |
| | 45609A | Plug (for 40673A) | 1 |
| 42 | 41706A | Connector | 1 |
| | 40039A* | Connector (for 40673A) | 1 |
| 43 | 40674A* | Cover Switch | 1 |
| 44 | 920065* | Nut, #8 | 7 |
| 45 | 40675A* | Cover Inlet | 1 |

NOTE: ♦ indicates a change has been made since the last publication of this manual.

* NOTE: used on machine model 07117A only.

Clarke®
American Sanders
FloorCrafter Belt Sander
Contact Wheel & Truck Assembly Drawing #3 10/01




Clarke®
American Sanders
FloorCrafter Belt Sander

Contact Wheel & Truck Assembly Parts List #3 10/01

| Ref No | Part No. | Description | Qty |
|--------|----------|-------------------------|-----|
| 1 | 20015A | Wheel, Contact | 1 |
| 2 | 60377A | Retainer, Contact Wheel | 1 |
| 3 | 81106A | Nut, Hex, Lock ¾-10 | 2 |
| 4 | 60376A | Plate, Drum End | 1 |
| 5 | 50913A | Belt, Abrasive | 1 |
| 6 | 87700A | Screw, ¼-20 x ½ | 1 |
| 7 | 20022A | Mainframe | 1 |
| 8 | 10244A | Tensioner Assembly | 1 |
| 9 | 20021A | Access, Door | 1 |
| 10 | 51211A | E-Ring, .25 Dia. | 5 |
| 11 | 60389A | Pin, Hinge | 1 |
| 12 | 60380A | Screw, Leveling | 1 |
| 13 | 60356A | Lever, Pressure Adj. | 1 |
| 14 | 51096A | Spring, Pressure Adj. | 1 |
| 15 | 962823 | Screw, ¼-20 x ½ | 5 |
| 16 | 60357A | Bracket, Pressure Adj. | 1 |
| 17 | 81209A | Nut, Large Flange | 1 |
| 18 | 60352A | Shaft, Yoke | 1 |
| 19 | 51279A | Bearing, Ball | 2 |
| 20 | 60355A | Spacer, Caster, Bearing | 1 |
| 21 | 60353A | Axle, Wheel | 1 |
| 22 | 20024A | Yoke, Caster | 1 |
| 23 | 87003A | Washer | 2 |
| 24 | 19611A | Wheel, Asm., Caster | 2 |
| 25 | 51226A | Bearing, Ball | 4 |
| 26 | 920196 | Nut, ½-13 | 2 |
| 27 | 66972A | Retainer, Bearing | 1 |
| 28 | 51190A | Bearing, Self Aligning | 2 |
| 29 | 980645 | Washer, ¾ Flat SAE | 3 |
| 30 | 962870 | Screw, ¾-16 x 1 | 3 |
| 31 | 51223A | Bearing, Ball | 1 |
| 32 | 51052A | Shaft, Arbor | 1 |

| Ref No | Part No. | Description | Qty |
|--------|----------|---------------------------|-----|
| 33 | 60394A | Key | 2 |
| 34 | 51051A | Bearing, Carrier | 1 |
| 35 | 51224A | Bearing, Ball | 1 |
| 36 | 86110A | Screw, ¾-16 x 1 | 4 |
| 37 | 51053A | Pully, Drum | 1 |
| 38 | 60378A | Retainer, Motor Pulley | 1 |
| 39 | 53538A | Rod, End. ¾ - 24 | 1 |
| 40 | 80119A | Bolt, Eye, ½ ID | 1 |
| 41 | 920208 | Nut, Hex, ¼-20 | 1 |
| 42 | 87007A | Washer | 3 |
| 43 | 920110 | Nut, Lk, 5/16-18 | 1 |
| 44 | 81102A | Nut, ¼-20 ESNA | 2 |
| 45 | 980679 | Washer | 1 |
| 46 | 52241A | Stop Pad | 1 |
| 47 | 51340A | Shaft, Truck Wheel | 2 |
| 48 | 51225A | Bearing, Ball | 4 |
| 49 | 167312 | Ring, Retaining | 2 |
| 50 | 60481A | Spacer | 2 |
| 51 | 50992A | Wheel, Asm., Truck | 2 |
| 52 | 962184 | Screw, ¼-20 x ¾, Set | 2 |
| 53 | 67817A | Spacer | 1 |
| 54 | 87003A | Washer | 2 |
| 55 | 20017A | Control Carriage | 1 |
| 56 | 51339A | Spacer, Truck Wheel | 1 |
| 57 | 80035B | Bolt, Shoulder, ¾ x 1¼ | 2 |
| 58 | 60375A | Axle, Truck | 1 |
| 59 | 20019A | Bracket, Leveling | 1 |
| 60 | 51203A | E-Ring | 1 |
| 61 | 60351A | Plate, Retaining | 1 |
| 62 | 962911 | Screw, 10-24 x ½ | 2 |
| 63 | 193944 | Grommet, Rubber, ¾ x 7/16 | 1 |
| 64 | 70236A | Label, Belt Tracking | 1 |
| 65 | 30186A | Bumper Front Edge | 1 |


Clarke®
American Sanders
Floorcrafter Belt Sander
Belt Tensioner Assembly Drawing #4 6/02



Clarke
American Sanders
Floorcrafter Belt Sander
Belt Tensioner Assembly Parts List #4 6/02


| Ref. No | Part No. | Description | Qty |
|---------|----------|--------------------------|-----|
| 1 | Ref. | Shaft, Guide Roller | 2 |
| 2 | Ref. | Bearing | 4 |
| 3 | Ref. | Roller Guide | 2 |
| 4 | 920208 | Nut, Hex ¼-20 | 3 |
| 5 | 60391A | Bolt, Shoulder | 2 |
| 6 | 60393A | Lever, Draw | 1 |
| 7 | 920296 | Nut, 10-24 | 3 |
| 8 | 747380 | Ring, Roller, Retaining | 2 |
| 9 | 902567 | Bearing, Ball | 3 |
| 10 | 67201B | Roller, Tension | 1 |
| 11 | 60395A | Screw, Link, Retaining | 2 |
| 12 | 60396A | Pin, Roller Shaft | 1 |
| 13 | 51211A | E-Ring | 4 |
| 14 | 80140A | Washer | 2 |
| 15 | 60383A | Shaft, Tension Roller | 1 |
| 16 | 699202 | Wire Tie | 1 |
| 17 | 60381A | Adjuster, Tracking | 1 |
| 18 | 20018A | Carriage, Tension Roller | 1 |
| 19 | 60382A | Link, Draw | 2 |
| 20 | 81303A | Nut, Hex Jam, ¼-28 | 1 |
| 21 | 81217A | Nut, ¼-20 | 3 |
| 22 | 60379A | Spring | 1 |
| 23 | 925546 | Pin, Roll | 2 |
| 24 | 962822 | Screw, ¼-20 x 5/8 | 1 |
| 25 | 51216A | Rod, End, Female | 2 |
| 26 | 962508 | Screw, ¼-20 x 3/4 | 1 |
| 27 | 60906A | Block, Wear | 1 |
| 28 | 87007A | Washer | 1 |
| 29 | 20020A | Support, Tensioner | 1 |
| 30 | 80020A | Bolt, Shoulder | 1 |
| 31 | 51221A | Link, Connecting | 1 |
| 32 | 51099A | Knob, Release | 1 |
| 33 | 80139A | Screw, ¼-20 x 7/8 | 1 |
| 34 | 60364A | Lever, Tension Relief | 1 |
| 35 | 962165 | Screw, 10-24 x 3/16 | 1 |
| 36 | 51277A | Ring, Retaining | 1 |
| 37 | 87052A | Washer, Flat, Nylon | 2 |
| 38 | 10247A | Cam, Release | 1 |
| 39 | 30087A | Boot, Belt Tensioning | 1 |
| 40 | 14704A | Guide Roller Assembly | 2 |

Clarke
American Sanders
FloorCrafter Belt Sander
Dolly Assembly Drawing & Parts List #5 6/02



| Ref No. | Part No | Description | Qty |
|---------|---------|--|-----|
| 1 | 51372A | Skewer, Clamp | 2 |
| 2 | 962216 | Screw, $\frac{3}{8}$ -16 x 1 $\frac{1}{4}$ | 4 |
| 3 | 962288 | Screw, $\frac{3}{8}$ -16 x 1 | 4 |
| 4 | 60345A | Bracket, Left Mounting | 1 |
| 5 | 39857A | Wheel | 4 |
| 6 | 80047A | Bolt, Shoulder $\frac{1}{2}$ Dia x 1 $\frac{1}{4}$ | 4 |
| 7 | 60347A | Brace, Dolly | 1 |
| 8 | 170883 | Washer, $\frac{3}{8}$ Lock | 4 |
| 9 | 87627A | Washer, .875 O.D. Bowed | 4 |
| 10 | 980648 | Washer | 8 |
| 11 | 60349A | Bracket, Left | 1 |
| 12 | 920260 | Nut, Hex $\frac{3}{8}$ -16 | 8 |
| 13 | 60348A | Bracket, Right | 1 |
| 14 | 60346A | Bracket, Right Mounting | 1 |
| 15 | 980646 | Washer, $\frac{1}{4}$ | 4 |

Clarke®
American Sanders
FloorCrafter Belt Sander
Motor Assembly Drawing & Parts List #6 7/04




| Ref No. | Part No | Description | Qty |
|---------|-----------|------------------------------|-----|
| 1 | 40151A | Motor, 4 Hp 60 Hz | 1 |
| | 40531A | Motor, 2.2 kW 50Hz | 1 |
| | ◆ 40672A* | Motor, 2.2 kW 50 Hz (07117A) | 1 |
| 2 | 60350A | Handle, Motor | 1 |
| 3 | 22904A | Enclosure, Motor, Start | 1 |
| 4 | 85806A | Screw, ¼-20 x ½ | 2 |
| 5 | 980657 | Washer, LK, ¼ | 2 |
| 6 | 962330 | Screw, 6-32 x ¾ | 4 |
| 7 | 697502 | Strain Relief | 1 |
| 8 | 60365A | Pulley, Motor | 1 |
| 9 | 51222A | Screw, Belt Tensioning | 1 |
| 10 | 57712A | Ring, Retaining, Motor Shaft | 1 |
| 11 | 60394A | Key ¼ x 1 ³⁄₈ | 1 |
| 12 | 73715A | Plate, Electric/Fire Warning | 1 |
| 13 | 10173A | Motor, Rear Mount | 1 |
| 14 | 962565 | Screw, ³⁄₈ -16 x ¾ | 6 |
| 15 | 87034A | Retainer, Motor Pulley | 1 |
| 16 | 962870 | Screw, ³⁄₈ -16 x 1 | 1 |

| Ref No. | Part No | Description | Qty |
|---------|---------|---------------------|-----|
| 17 | 980603 | Washer | 1 |
| 18 | 85833A | Screw | 1 |
| 19◆ | 41304A | Capacitor, 40 MFD | 1 |
| 20 | 41305A | Capacitor, Start | 1 |
| 21 | 47378A | Switch, Start | 1 |
| 22 | 170674 | Connector, Wire Nut | 2 |
| 23 | 45604A | Plug, Electric | 1 |
| 24 | 41945A | Cord, Motor | 1 |
| 25 | 52769A | Fan Cover | 1 |
| 26 | 40546A | Fan | 1 |
| 27 | 962727* | Screw, 8 -32 x ½ | 8 |
| 28 | 10603A* | Inlet Asm. | 1 |
| 29 | 40677A* | Enclosure Switch | 1 |
| 30 | 87700A* | Screw, ¼-20 x ½ | 2 |
| 31 | 46323A* | Relay | 1 |
| 32◆ | | Capacitor 60 MFD | 1 |
| 33 | 40676A* | Switch Control | 1 |


* NOTE: used on machine model 07117A only.

NOTE: ◆ indicates a change has been made since the last publication of this manual.

Clarke
American Sanders
 Floorcrafter
 Wiring Diagram 1/01 (models 07104A and 07111A)



Clarke
American Sanders
 Floorcrafter
 Wiring Diagram 1/04 (model 07117A)



ALTO[®] PRODUCT SUPPORT BRANCHES

U. S. A. Locations

CORPORATE OFFICE

ALTO U.S. Inc., St. Louis, Missouri
16253 Swingley Ridge Road, Suite 200
Chesterfield, Missouri 63017-1725

PRODUCTION FACILITIES

Clarke[®], Springdale, Arkansas
2100 Highway 265
Springdale, Arkansas 72764
(479) 750-1000
Customer Service - 1-800-253-0367
Technical Service - 1-800-356-7274

American Lincoln[®], Bowling Green, Ohio 43402
1100 Haskins Road

SERVICE FACILITIES

Clarke[®], Elk Grove, Illinois 60007
2280 Elmhurst Road
(847) 956-7900

Clarke[®], Denver, Colorado 80204
1955 West 13th Ave.
(303) 623-4367

Clarke[®], Houston, Texas 77040
7215 North Gessner Road
713-937-7717

SERVICE AND SALES FACILITY

American Lincoln[®] / Clarke[®], Madison Heights,
Michigan 48071-0158
29815 John R.
(810) 544-6300

American Lincoln[®] / Clarke[®], Marietta, Georgia 30066
1455 Canton Road
(770) 973-5225

SALES AND DISTRIBUTION CENTER

Clarke[®], Secaucus, NJ 07094
74 Henry Street
(201) 864-5503

Clarke[®]
Clarke American Sanders
A.L. Cook
Customer Service Headquarters and Factory
2100 Highway 265
Springdale, Arkansas 72764
(479) 750-1000
Technical Service
1-800-356-7274

European Locations

PRODUCTION FACILITIES

ALTO Danmark A/S, Aalborg
Blytaekervej 2
DK-9000 Aalborg
+45 72 18 21 00

ALTO Danmark A/S, Hadsund
Industrikvarteret
DK-9560 Hadsund
+45 72 18 21 00

SALES SUBSIDIARIES

Clarke[®] Canada Ltd., Rexdale Ontario
24 Constellation Ct.
(416) 675-5830

ALTO Overseas Inc., Sydney (Australia)
1B/8 Resolution Drive
Caringbah NSW 2229
+61 2 9524 6122

ALTO Cleaning Systems Asia Pte Ltd., Singapore
No. 17 Link Road
Singapore 619034
+65 268 1006

ALTO Deutschland GmbH, Bellenberg (Germany)
Guido-Oberdorfer-Straße 2-8
89287 Bellenberg
+49 0180 5 37 37 37

ALTO Cleaning Systems (UK) Ltd., Penrith
Gilwilly Industrial Estate
Penrith
Cumbria CA11 9BN
+44 1768 868 995

ALTO France S.A. Strasbourg
B.P. 44, 4 Place d'Ostwald
F-67036 Strasbourg
Cedex 2
+33 3 8828 8400

ALTO Nederland B.V.
Postbus 65
3370 AB Hardinxveld-Giessendam
The Netherlands
+31 184 677 200

ALTO Sverige AB, Molndal (Sweden)
Aminogatan 18
Box 4029
S-431 04 Molndal
+46 31 706 73 00

ALTO Norge A/S, Oslo (Norway)
Bjornerudveien 24
N-1266
+47 2275 1770

Clarke® American Sanders U. S. Warranty

This Clarke American Sanders Industrial/Commercial Product is warranted to be free from defects in materials and workmanship under normal use and service for a period of one year from the date of purchase, when operated and maintained in accordance with Clarke American Sanders's Maintenance and Operations Instructions.

This warranty is extended only to the original purchaser for use of the product. It does not cover normal wear parts such as electrical cable or V-belts.

If difficulty develops with the product, you should:

(a). Contact the nearest authorized Clarke American Sanders repair location or contact the Clarke American Sanders Service Operations Department, 2100 Highway 265, Springdale, Arkansas 72764, for the nearest authorized Clarke American Sanders repair location. Only these locations are authorized to make repairs to the product under this warranty.

(b). Return the product to the nearest Clarke American Sanders repair location. Transportation charges to and from the repair location must be prepaid by the purchaser.

(c). Clarke American Sanders will repair the product and or replace any defective parts without charge within a reasonable time after receipt of the product.

Clarke American Sanders's liability under this warranty is limited to repair of the product and/or replacement of parts and is given to purchaser in lieu of all other remedies, including INCIDENTAL AND CONSEQUENTIAL DAMAGES.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE SPECIFIED HEREIN. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF. NO WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY, SHALL BE IMPLIED. A warranty registration card is provided with your Clarke American Sanders product. Return the card to assist Clarke American Sanders in providing the performance you expect from your new floor machine.

Clarke, 2100 Highway 265, Springdale, Arkansas 72764.

Clarke American Sanders reserves the right to make changes or improvements to its machine without notice.

Always use genuine Clarke American Sanders Parts for repair.

Clarke®
American Sanders

Division of
ALTO®

**2100 Highway 265
Springdale, Arkansas, 72764**